


QuickZip™ Waterfall

ASSEMBLY INSTRUCTIONS



QuickZip™ Waterfall

ASSEMBLY INSTRUCTIONS


BOX CONTENTS - WATERFALL HARDWARE



(2) Waterfall Clamps




(2) Connected Poles



(3) Crossbars



(2) End Poles



(2) Corner Poles



(4) Shelf Screws



(2) Shelves



(4) Shelf Brackets



(1) TV Stand Graphic
(Ships Separately)

BOX CONTENTS - TV MOUNT



(1) TV Mount
Main Support



(2) TV Mount
Brackets



(8) M5/M6
Washers



(4) M6 x 24mm
Screws



(4) M5 x 24mm
Screws




(2) M5 x 35mm
Screws

NOT FOR USE WITH DISPLAY



(4) Wall Anchors




(4) Wall Anchor
Screws



(4) Spacers


1

Assemble the Frame




2

Connect the Crossbars




3

Install the Graphic




4

Install Shelves



5


Attach TV mount



Screw the TV Mount on the display using the M6 Screws and M6 washers.

6


Attach Brackets to Monitor



Use the M5 x 24mm screws.

7

Attach to Backdrop



8

Mount the Monitor

